



## AT E1.04B FLOOR LINE DEFLECTION SLIP JOINT (ISO)

### AIRTIGHT SYSTEM

- NOTE:
- 1 Sliding stud connection. Slotted track typical.
  2. Sheathing screws for upper floor sheathing are to be fastened into track at under side of slab. Do not fasten screws for upper sheathing into studs of lower story.
  3. CAUTION: If nested double tracks are used for deflection, sheathing screws must not interfere with track sliding

Disclaimer: The design, specifications, and construction shall comply with all local building codes and standards. Parex USA installation guidelines are for general information and guidance only and Parex USA specifically disclaims any liability for the use of this design, and for design, engineering, or workmanship of any project. The assembly shall be designed to prevent condensation within the assembly. The designer and the user shall provide final drawings and specifications. Products shown other than those manufactured by Parex USA are shown for clarity of the Parex USA product only. Contact the manufacturer of such other products for installation instructions.